

- 1) ALL DUCT DIMENSIONS ARE SHOWN IN INCHES UNLESS OTHERWISE SHOWN.
- 2) ALL DUCT DIMENSIONS ARE CLEAR INSIDE DIMENSIONS.
- 3) SEAL AROUND ALL DUCT & PIPE PENETRATIONS THROUGH NEW WALL WITH FIRE STOP SEALANT SUCH AS OWI CORNING CATALGO #8000 OR EQUAL.
- 4) SEAL AROUND ALL EXISTING OPENINGS IN WALL WITH THE FIRESTOP SEALING COMPOUND SO AS TO BE AIR TIGHT.
- 5) ALL EXISTING DUCT DIMENSIONS TO BE VERIFIED BY FIELD MEASUREMENTS BEFORE COMMENCEMENT OF WORK BY THE CONTRACTOR.
- 6) VERIFY EXISTING DUCT DIMENSIONS IN FIELD, DIMENSIONS SHOWN ARE FROM



WTC-945.071 M-802